



Directions:

Loop a long length of 0.004" polyester monofilament around the thumbtack. Tie a simple double overhand knot around the pin. Remove the pin and tighten the knot. Hold knot with thumbnail and pull on excess. Cut off excess leaving 10mm (min) tails.

Cardboard, black for white polyester,  
white for black polyester